

Practical-4

Aim:

Setup and configure a LAN using a switch and ethernet cables in your lab.

how to setup lan:

Step 1:

Plan and design an appropriate network topology taking into account network requirement and equipment location.

Step 2:

You can take 4 computers, a switch with 8, 16 or 24 ports which is sufficient for networks of these sizes and 4 ethernet cables.

Step 3:

connect your computers to network switch using a ethernet cable, which is as simple as plugging one end of the ethernet of the into your computer and other end into your network switch.

Step 4: Assign IP addresses to your PCs.

1) log on to the client computer as administrator or as owner.

2) click network and internet connections.

3) Right click local area connection → go to properties → select Internet protocol → click on properties → select use the following ip address option and assign ip address.

step 5: configure a network switch:

- 1) Connect your computer to the switch: To access the switch's web interface, you will need to connect your computer to the switch using an ethernet cable.
- 2) log in the web interface: open a web browser and enter the IP address of the switch in the address bar.
- 3) configure basic settings: once you're logged in you will be able to configure basic settings for the switch.
- 4) assign IP address as: 10.1.1.5 Subnet mask 255.0.0.0.

step 6:
check the connectivity between switch and other machine by using ping command in the command prompt of the device.

step 7:
select a folder → go to properties → click sharing tab → share it with everyone on the same LAN.

step 8:
Try to access the shared folder from the others computer of the network.

Observation:

PC1: 10.1.1.1 subnet mask : 225.0.0.0
PC2: 10.1.1.2 subnet mask : 225.0.0.0.
PC4: 10.1.1.4 subnet mask : 225.0.0.0
PC3: 10.1.1.3 subnet mask : 225.0.0.0.

Outcome:

- all PCs are successfully connected to the network and they can communicate with each other via switch.
- shared folder is accessible from other PCs.
confirming network resource sharing.

Challenge:

ensure no duplicate ips are assigned to devices which can cause connectivity issues.

Result:

Thus setting up and configure a LAN using switch and ethernet cable is established.

Done
3/8/2020